



E L E

N K

E R

ROLLATOR
WALKER
KLD-9224-PU

ROLLATOR
WALKER
KLD-9224-PU



USER MANUAL

Parts:



- | | |
|---------------------------|------------------------------|
| 1 Sit-to-stand handle bar | 9 Handle bar tube |
| 2 Backrest | 10 Short plum hex shape knob |
| 3 Seat | 11 Seat belt |
| 4 Storage bag | 12 Long plum hex shape knob |
| 5 Footrest | 13 Star Shape Knob |
| 6 Front wheel | 14 Cane/Umbrella holder |
| 7 Handgrip | 15 Rear wheel |
| 8 Handbrake | |

SET-UP INSTRUCTIONS

STEP 1

Unbox the walker on a level floor.



ACCESSORIES LIST



2xshort plum hex shape knobs
for handle bar tube



2xlong plum hex
shape knob



2xstar shape knobs



1x cane/umbrella holder



1x cup holder

STEP 2

Take Out the Main Frame



Unfold the main frame, then press seat to lock it(fig 2).



STEP 3

Front Wheels Assembly


Insert front wheel into the main frame(fig 3), then secure it with long plum hex shape knob(fig 3-1,3-2), repeat the same steps on the other side (fig 3-3)(There are labels on each tube"L1-L1, R1-R1").




STEP 4

Rear Wheels Assembly

Press spring button then insert rear leg into the main frame(fig 4,4-1), secure rear leg with star shape knobs(fig 4-2,4-3), repeat the same steps on the other side(fig 4-4)(There are labels on each tube"L2-L2, R2-R2").






STEP 5

Handle Bar Tube Assembly

Insert handle bar tube into the main frame, set the desired height(fig 5, 5-1). Then secure it with short plum hex shape knob(fig 5-2), repeat the same steps on the other side(fig 5-3)(There are labels on each tube"L3-L3, R3-R3").




STEP 6 Storage Bag Assembly

Hang storage bag on stick of seat.




STEP 7 Cane/Umbrella Holder Assembly

Cane holder knob is on the left rear wheel leg, insert cane holder into cane knob(fig7, 7-1).



STEP 8 Cup Holder Assembly

Cup holder knob is on the right of handle bar, insert cup holder into cup holder knob(fig8, 8-1).



STEP 9 Brake Cable Hook and Loop Fastener Assembly



Affix the brake cable to the main frame with hook and loop fastener(fig 9).



STEP 10

The Footrest Assembly


Install the footrest on front of wheel(fig 10, 10-1, 10-2). It also can be affixed on side frame holder when you use it as rollator(fig 10-3,10-4).



One-Hand Folding

Pull up the seat strap to fold the walker(fig 11, 11-1), then use seat hook to secure the walker in place(fig 11-2).





The Curb Climber

Use it to overcome obstacles such as curbs and thresholds.




Handbrakes Operation

1. Squeeze to slow.
2. Push down to lock the rear wheels.



Transform Rollator into Transport Wheelchair

- Step1: flip over the backrest(fig 14).
- Step2: affix the footrest(fig 14-1).




How to Adjust Brakes

Brake Issue: The brake cannot engage rear wheel when squeezing handbrake (fig A).



Adjust Rear Brake Position

Tools : Plier and 10mm wrench(or 8mm+10mm wrenches)(fig 1).
Use 10mm wrench to hold M6 nut, then use 8mm wrench or plier to turn M5 nut clockwise(fig 2-3). And brake will be closer to wheel(fig 4). Then squeeze handbrake, if it doesn't work, repeat the steps until rear brake can engage wheel.



CONTACT US

For any defects, parts missing, use or repair concerning our products, please contact us first, our customer service will reply within 24 hours and offer a good solution. Thank you for your support.

1. elenkerservice@hotmail.com
2. Amazon Message: Click the Sold by "store name" under the buy box, then "ask a question". (Amazon Buyer)
3. Customer Help Line: 800-513-5727


WARRANTY


- * You may return most new, unopened items sold and fulfilled by Amazon within **30** days of delivery for a full refund.
- * Defects in material accessories and non-durable components such as wheels, brakes, seat, handgrips and under NORMAL use for the **lifetime** warranty of the original consumer purchaser.
- * The warranty does not extend to device failure due to owner misuse or negligence, or normal wear, tear and need periodic replacement.
- * During warranty periods, our warranties cover all parts labor and shipping for repairing this walker.


WARNINGS


To ensure your safety in using ELENKER Rollator Walker, all the following instructions must be followed

 The maximum load of the walker is 300lbs.

 DO NOT use walker, if there is apparent damage or if any parts are missing.

 Ensure that brakes, height adjustment bolts or any other moving parts are in good condition and check all screws and fasteners, and retighten if necessary.

 DO NOT use on stairs, escalators, moving sidewalks, or go up or down inclines greater than 15% or diagonally across inclines greater than 5%.

 Be careful to avoid pinching your fingers while raising and lowering the handle bar and opening and closing the rollator walker frame.